

EMF-VISUAL

User Manual

Contents

1	Introduction	5
1.1	Purpose	5
2	Presentation	5
2.1	What EMF-VISUAL is	5
2.2	Input/Output	5
2.2.1	Input	5
2.2.2	Output	5
2.2.3	Licence	5
2.3	Operating systems	5
2.4	Launching EMF-VISUAL	6
3	Software overview	7
3.1	Main window	7
3.2	Files operation	8
3.3	Using dock windows	8
4	Scene management	9
4.1	Creating a scene	9
4.1.1	Object	10
4.1.1.1	Geometry representation	10
4.1.1.2	Object properties	11
4.1.2	Group	12
4.1.3	Antenna	13
4.1.3.1	Band properties	13
4.1.3.2	Antenna properties	14
4.1.4	Camera	15
4.2	Edit tool bar	16
4.2.1	Edition tool bar	16

4.2.2	Hierarchy tool bar	17
4.2.3	Distance tool bar	17
4.2.4	Browser	19
4.2.5	Property	20
4.3	View tool bar	21
4.3.1	Observers selection	21
4.3.2	Selection tool	21
4.3.3	Information tool	22
4.3.4	Move tool	22
4.3.5	Dragger tool	23
4.3.6	Handling a scene	24
4.3.6.1	Centred navigation mode	24
4.3.6.2	Pan navigation mode	25
4.3.6.3	Zoom	25
4.3.7	View Settings	25
4.3.7.1	General panel	26
4.4	Editing the search directories	27
4.4.1	Purpose	27
4.4.2	Search directory panel	27
4.4.3	Refresh the scene	28
4.5	Importing scene	28
4.6	Tools node	29
4.6.1	Volume	29
4.6.2	Plane	29
5	Simulation management	29
5.1	Computation volume	29
5.1.1	Volume properties	30
5.1.2	Sampling of the volume	31
5.2	Launch computation	33
5.2.1	Results file format	34

5.2.1.1	Header	34
5.2.1.2	Raw data	35
5.3	Results visualisation	35
5.3.1	Visualisation	36
5.3.1.1	Isosurface	36
5.3.1.2	Cross section	37
5.3.2	Recommendation file	41
5.3.3	Recommendation	42
5.3.4	Custom standard file	43
5.3.4.1	Genenic reference value computation formula	43
5.3.4.2	Custom standard file format	43
5.3.4.3	Example of custom standard file	44
5.3.5	Legend	45
5.3.5.1	Coloring method	46
5.4	Results Menu	47
5.4.1	Save cross section	47
6	Delivered features	50
6.1	3D database	50
6.2	Antennas	53
6.2.1	Diagram antenna files	53
6.3	Recommendation files	53

1 Introduction

1.1 Purpose

This document is the user manual of the EMF-VISUAL software.

2 Presentation

2.1 What EMF-VISUAL is

EMF-VISUAL simulates scattered fields from GSM antennas in a 3D virtual database using ray-tracing techniques. EMF-VISUAL can visualize raw computed fields or safety limitation areas defined by any recommendation.

EMF-VISUAL runs on a single PC system.

2.2 Input/Output

2.2.1 Input

- **.scnx* The input data of a EMF-VISUAL simulation is a configuration file. Moreover, EMF-VISUAL can import configuration file (**.iconf*) from EMF-Visual V3, the previous version.
- **.bdd* Files that define the geometry of an environment.
- **.evc* Recommendation files.
- **.txt* Custom standard files.

2.2.2 Output

- Simulation results in Tecplot format.

2.2.3 Licence

EMF-VISUAL requires EMF-VISUAL licence. Contact OKTAL-SE (<http://www.oktal-se.fr>)

2.3 Operating systems

EMF-VISUAL is available on:

OS	32-bit executable	64-bit executable
Windows XP 32-bit	OK	-
Windows XP 64-bit	OK	OK
Windows Seven 64-bit	OK	OK

The software requires a graphics card with 3D acceleration if GPU computation is performed and a three-button mouse. NOTE: EMF-VISUAL may use GPU resources for its simulation. Only NVIDIA CUDA-enabled GPUs (version 9 or higher) can run the software. Compatible configurations are listed at: http://www.nvidia.com/object/cuda_gpus.html (COMPUTE CAPABILITY \geq 1.1).

2.4 Launching EMF-VISUAL

The executable of EMF-VISUAL depends on version.

Here are the valid launcher:

- 32 bits version: Software\Program_Win32\EMF-VISUAL\EMF_VISUAL.exe
- 64 bits version: Software\Program_Win32\EMF-VISUAL_64\EMF_VISUAL.exe

Note: Executable under Software\Program_Win32\Bin\EMF-VISUAL\EMF-VISUAL.exe or Software\Program_Win32\Bin_64\EMF-VISUAL\EMF-VISUAL.exe are not meant to be launched.

3 Software overview

3.1 Main window




Figure 1: Main window

The main window of EMF-VISUAL is composed of:

- A menu bar (1) that contains the main commands of the software
- A general toolbar (2) for scene management.
- A central area (3) that displays both 3D scene and simulation results (fields, recommendation area). A specific toolbar (4) provides functionalities to control 3D view.
- Five dock windows that are initially placed around the central area:
 - The "Browser" window (5): this dock window contains the panels dedicated to Scene's edition, computation Tool's edition.
 - The "Properties" window (6): this dock window sets parameters of selected entity.

- The "Computation results" window (7): this dock window sets result to display with several parameters and kind of visualisation.
- The "Recommendation property" window (8): this dock window defines recommendation file.
- The "Messages" window (9): this dock window displays all messages.

3.2 Files operation

A configuration file is an XML document with the `.scnx` extension.

To create a new scenario, select the  **New (Ctrl + N)** command from the **File** menu.

To load an existing scenario, select the  **Open... (Ctrl + O)** command from the **File** menu.

To import an old configuration file in `.iconf` format, select the **Import...** command from the **File** menu. See 4.5 for more details.

To save the current scenario, select the  **Save (Ctrl + S)** command from the **File** menu.

To save the current scenario under a new name, select the **Save as...** command from the **File** menu.

3.3 Using dock windows

Each dock window has in a title bar and a content area. The title bar displays the window title ("Scenario" for example), a float button and a close button . A dock window can have different states:

- The docked state (the default one): in this state, the dock window is visible and placed on the east, west, north or south side of the central area. To move a dock window, click on its title bar with the left mouse button, hold it down while moving the mouse at the new emplacement and release the mouse button.
- The floated state: in this state, the dock window floats above the workspace. To toggle the state of a dock window from docked to floated and vice-versa, click on its float button.
- The hidden state: in this state, the dock window is hidden. To hide a dock window, click on its close button. To retrieve a dock window that has been hidden, click with the right button of the mouse on the title of an another dock window or on the toolbar. The following window will appear.




Figure 2: Dock windows management

Select the dock window to retrieve by clicking on its title. In a more general approach, this window is a central place to manage the visibility of all dock windows and toolboxes.

When a dock window is floated or hidden, the area that it frees inside the workspace can be occupied by a view, making its manipulation more comfortable. The picture below shows the software with all dock windows hidden.

4 Scene management

There is no computation without any 3D database. This section shows how to build a 3D scene with EMF-VISUAL.

4.1 Creating a scene

Entities of the scene are under the *Scene* node.




Figure 3: Scene node

There are several kind of entities. To add an entity **Right click on *Scene node* > Add Entity**. You can choose among the following entities

- Object
- Group
- Antenna

Another way to add entity is to right click on view windows, a panel will be displayed: **Right click on *view window* > Add Entity**

Position and orientation properties are under Properties dock widget.

Every entity can be moved with moving tools described in previous chapters(See 4.3.4 and 4.3.5)

4.1.1 Object

4.1.1.1 Geometry representation

An *object* entity represents a solid actor using a geometry file. It is taken into account during the electromagnetic computation. To add an object entity: **Right click on *Scene node* > Add Entity > Object**. One can choose a geometry file from the displayed file browser. An object file is a **.bdd* (SDM geometry files) or **.bsg* (OpenSceneGraphe files). The *Scene* node acts as an object entity, except that it is unique and can not be positioned.

4.1.1.2 Object properties






Figure 4: Object properties

-  Open new geometry file. Select the new file from the displayed file browser.
-  Remove current geometry file.

One can modify the size of entity along X,Y,Z dimension with parameters (*Width,Depth,Height*).

4.1.1.2.1 Material definition



A good geometry is not enough for EM computation, a well definition of material with correct physical property is required. EMF-Visual allows user to set material to object.

Click on **EM Material** box to set material to object from a list of predefined materials.





Figure 5: List of predefined materials

Open the material manager window, **Simulation > Display material manager** to get physical properties (permittivity, conductivity and thickness) of materials.



	Name	Index	Permittivity	Conductivity	Thickness
1	Perfect Electric ...	0	1	1e+20	0
2	Decorative	1	0	0	0
3	Concrete T=-9....	2	7	0.06	0.2
4	Light Concrete ...	3	5	0.03	0.2
5	Brick T=-2.3dB	4	4	0.0056	0.2
6	Plywood T=-1....	5	3	0.0056	0.2
7	Particles Panel ...	6	3	0.0111	0.05
8	Wood T=-0.7dB	7	2.5	0.0017	0.03
9	Glass T=-1dB	8	6	0.0006	0.01
10	Reinforced Con...	9	7	0.09	0.2

Figure 6: Material Manager window

4.1.2 Group

This entity has no interaction with the electromagnetic computation. It is useful for moving several entities attached to it. To add an object entity: **Right click on Scene node > Add Entity > Group**

4.1.3 Antenna

An *antenna* entity represents a electromagnetic antenna using an antenna description file. It is taken into account during the electromagnetic computation. To add an antenna entity: **Right click on Scene node > Add Entity > Antenna**. An antenna file is a *.src. An antenna may be composed of several bands.




Figure 7: Multi bands

4.1.3.1 Band properties




Figure 8: Multi bands

- *Name* Name of the band
- *Gain* Gain of antenna in this band
- *Electric tilt (°)* Electric tilt in degree.

- *Frequency (MHz)* Frequency of the band in MHz
- *Power (W)* Power in Watt
- *Enabled* If unchecked, this band is disabled.

4.1.3.2 Antenna properties




Figure 9: Antenna properties

- Checking *Show radiation area* box displays the radiation field in the 3d window.






Figure 10: Antenna radiation area



-  Open new antenna file *.src. Select the new file from the displayed file browser.
- *Horizontal aperture* is expressed in degree. It can't be edited.
- *Vertical aperture* is expressed in degree. It can't be edited.

4.1.4 Camera

Camera entity defines the point of view of the view window of EMF-Visual.




Figure 11: Camera properties

- *Near plane (m)* defines the distance of the near plane of the view. Every geometry in the field of view before the near plane is not rendered in view window.
- *Far plane (m)* defines the distance of the far plane of the view. Every geometry in the field of view above the far plane is not rendered in view window.
- *Aperture (°)* defines the aperture of the camera.

4.2 Edit tool bar







Figure 12: Edit Tool Bar

4.2.1 Edition tool bar



Figure 13: Edition tool bar

Standard entity edition tool bar.





-  Cut selected entity in scene hierarchy
-  Copy selected entity in scene hierarchy
-  Paste copied entity under selected entity hierarchy
-  Remove selected entity from scene hierarchy

4.2.2 Hierarchy tool bar



Figure 14: Hierarchy move tool bar

The edit tool bar allows to change position of entity in the scene hierarchy.

-  Move selected entity up in scene hierarchy
-  Move selected entity down in scene hierarchy
-  Move selected entity up in scene hierarchy
-  Move selected entity up in scene hierarchy

4.2.3 Distance tool bar



Figure 15: Distance tool bar

The distance tool measures distance between 2 points.

- Clicking on button   creates a *Distance* entity in *Tools node* and adds the first point.




Figure 16: Distance tool: first point

The first point is selected after it has been created and can be moved using *Move tool* (see 4.3.4), *Dragger tool* (see 4.3.5) or changing position in properties panel (see 4.2.5).

- Clicking on button   adds the second point.

Distance between these 2 points is displayed

- in *Tools node*




Figure 17: Distance in *Tools node*

- in *3d view scene*




Figure 18: Distance in *3d view*

The second point is selected after it has been created and can be moved using *Move tool* (see 4.3.4), *Dragger tool* (see 4.3.5) or changing position in properties panel (see 4.2.5).

The distance is updated while changing second or first point position.

4.2.4 Browser

Each entity of the scene can be selected in this dock window. Properties of selected entity are displayed in "Property" window and may change depending on kind of selected entity.




Figure 19: Dock windows management

When the *SHIFT* key is pressed, a group of entity can be selected. Clicking on an entity while *CTRL* key is pressed, appends it to the current selection.

There are 2 main nodes: *Tools node* and *Scene node*. *Tools node* contains utility entities:

- *Distance*. See 4.2.3.
- *Volume* for computation
- *Plane* for cross section visualization.

In the browser window, a checked entity is an activated entity.




Figure 20: Checked entity

A checked entity is visible in the 3d view window and is taken into account for computation.




Figure 21: Unchecked entity

An unchecked entity is **not** visible in the 3d view window. Moreover, depending on type of the entity, it will **not** be taken into account the same way.

- *Geometry* The geometry of entity is not taken into account for computation
- *EntityGroup* All entities under the EntityGroup are not taken into account
- *Antenna* The field emitted by the antenna is not computed for activated volumes.
- *Volume* The field from valid antennas is not computed inside the unchecked volume.
- *Plane* The cross section is not computed.

4.2.5 Property

This dock window show property for selected entity.

X (m)	<input type="text" value="0"/>
Y (m)	<input type="text" value="0"/>
Z (m)	<input type="text" value="0"/>
Azimuth (°)	<input type="text" value="0"/>
Tilt (°)	<input type="text" value="0"/>
Roll (°)	<input type="text" value="0"/>

Figure 22: Position and orientation properties

Properties are different from a kind of entity to another but they share at least the same position and orientation properties

- X
- Y
- Z
- Azimuth
- Tilt
- Roll

A position is represented with conventional (X, Y, Z) coordinates which are expressed in meters. An orientation is represented with a (Azimuth, Tilt, Roll) triplet (also called Euler angles) whose

components are expressed in degrees. The azimuth value is a rotation about the Z axis and is positive clockwise if looking along the +Z axis. The tilt value is a rotation about the X axis and is positive above the XY plane. The roll value is a rotation about the Y axis after head and pitch have been applied and is positive clockwise if looking along the +X axis.




Figure 23: Reference

4.3 View tool bar



Figure 24: View tool bar

4.3.1 Observers selection





Figure 25: Observers selection


The option is limited to one camera.


4.3.2 Selection tool

To activate the selection tool, **Click on**  button or press the S key. Then, selecting is performed by left clicking on an entity. When the CTRL key is pressed while clicking, the picked element is

appended to the selection.

4.3.3 Information tool

To activate the information tool, **Click on**  button or press the *I* key. This tool displays a dialog providing information about picked point. Then **Click on a point** in 3d view window to get information about it. By default, before clicking on a point, no element is picked.



The displayed information about the picked element is:


- its name
- its type
- its absolute position
- its absolute orientation

The displayed information about the picked point is:

- its absolute position
- its distance to the observer
- the path of the texture picked

Figure 26: Information window


4.3.4 Move tool

Move tool allows the user to set position of the currently selected entity on the scene from 3d view. To activate the *Move tool*, **Click on**  button or press the *M* key. Then, **left click** on the scene to move the currently selected entity or control point to the designated location. The user has to left

click on entity so that selected entity is moved.

4.3.5 Dragger tool

Dragger tool allows moving and orientating the currently selected entity by manipulating a 3D dragger.

To activate the dragger tool, **Click on**  button or **Press D key**. To move an entity, **Left Click on** one of the dragger's axes and drag it to the desired position. To orientate an entity, left click on one of the dragger's rings and drag it to rotate the dragger.




Figure 27: Dragger tool activated on object

While dragger tool is activated, **Press Space Bar** to switch the dragger type from moving and rotating mode to scaling mode and the contrary.




Figure 28: Dragger tool in scale mode

4.3.6 Handling a scene

4.3.6.1 Centred navigation mode

EMF-Visual uses the centred navigation mode. The observer moves around a centre point picked in the scene.

Keep the middle mouse button pressed and move the mouse to change view direction. The position and orientation are not modified. By default, the centre point is the centre of the scene.





Figure 29: Centred navigation modes

Centring mode can be selected in a combo box in View tool bar:

- *Center On Point*: Click on *Center On Point* action or **press C key** then click on specific point in the scene that will be the centre.
- *Center On Entity*: Click on *Center On Entity* action then select the entity among the entities list that will be the centre.

- *Center On Selection*: Click on *Center On Selection* action, the centre of the last selected object will be the centre of the view. It requires to have already selected at least one object.

4.3.6.2 Pan navigation mode

Keep H key pressed - the cursor of the mouse changes to an hand () - **keep the left mouse button pressed** and move the mouse to translate view direction.

Releasing *H* key switches back to centred navigation mode.

4.3.6.3 Zoom

Scroll up the wheel of the mouse to zoom in, scroll down the wheel to zoom out.

4.3.7 View Settings

Click on  to display View settings panels.




Figure 30: View Setting panels

4.3.7.1 General panel




Figure 31: General panel

This panel defines a rendering configuration of the view. To change the kind of the overlay statistics (i.e. information drawn above the image) , select one of the entry from the "Statistics" drop down list:

- *None* No statistics are displayed (default)
- *Frame rate* The frame rate (Hz) is displayed in the rendering window
- *Timings* A chart containing the timings of each stage of the rendering pipeline is displayed in the rendering window
- *Scene geometry* The frame rate, the number of rendered vertices and triangles are displayed in the rendering window

To change the draw style of the rendering , select one of the entry from the "Draw style" drop down list:

- *Wireframe* Only the edges of the polygons are rendered
- *Filled* The polygons are rendered without the textures
- *Textured* The polygons are rendered with the textures (default)
- *Scribed* The edges of the polygons are rendered over the textures

The alpha threshold is used to discard transparent pixels. Every pixels whose alpha is below the threshold are not rendered. The default value is 0.7.

When the "Activate shaders" item is checked , the rendering pipeline uses the programmable shaders instead of the fixed functionality of the graphics card, and allows several specific objects (such as water hyper-textures) to be rendered with more realism. This check box is disabled if there is no NVIDIA graphic board.

When the "Frame overlay" item is checked , a 3D frame is displayed at the top-right corner of the view.

To configure how the resolution of the rendered image is handled , select an entry from the "Image resolution" drop down list:

- Extend for observer/Crop for sensor: The image is extended to the window size if the default observer is selected. When a sensor is selected, the image is cropped to its resolution.
- Always extend: The image is always extended to the window size.
- Always crop: The image is always cropped to the resolution of the selected camera.

4.4 Editing the search directories

4.4.1 Purpose

The scene structure refers to several files needed for the computation. These files can be 3D geometry files, antenna diagram, etc... When saving a configuration file, these dependencies are written relatively to the scene file path (if there are on the same disk partition). A dependency may also refers to other files. To cope with multiple recursive references, paths to all references are added to search directories. Search directories are saved in an environment file *.env* with the same configuration file name.

4.4.2 Search directory panel

To edit the search directories of the current configuration. **Edit > Search directories**








Figure 32: Scene node

-  Add a new path to the search directories. Select the new directory from the displayed file browser.
-  Remove the selected path from the search directories.

The order of the search directories list is meaningful. During the search process, the path at the beginning of the list will be first explored, then the second, and so on.

-  Increase the priority of selected path, i.e. grant it a higher rank in the list
-  Decrease the priority of selected path, i.e. grant it a lower rank in the list

4.4.3 Refresh the scene

Refreshing the scene will take into account edited search directories. **File > Refresh all.**

4.5 Importing scene

To insure backward compatibility, EMF-VISUAL can import *.*iconf* from EMF-VISUAL V3.x.

To import a scene in *.*iconf* file format: **File > Import**

Select the output directory from the displayed file browser. *Data_Objects* and *Data_Scnx* will be created.

Edit the search directory to add *Textures* directory see 4.4 Editing the search directories. Indeed, just after importing a scene, entities will appear without texture. Appending directory to *Textures* will set textures to geometry.

4.6 Tools node

Under the *Tools node*, only computation volume and cut plane for cross section visualisation are allowed.

4.6.1 Volume

See 5.1 Computation volume

4.6.2 Plane

See 5.3.1.2 Cross section

5 Simulation management

5.1 Computation volume

EMF-Visual is meant for field computation on volume. This volume has to be sampled for computation. Defining a volume requires 2 steps.

- first step: Defining size and position of the volume
- second step: Defining the sampling of the volume.

Note that *no computation is launched if no computation volume is defined.*

Note : The software handles several computation volumes.

To add a computation volume. **Right click on Tools node > Add entity > Volume**

A volume added in Scene node is not taken into account for computation




Figure 33: Computation Volume

5.1.1 Volume properties




Figure 34: Volume properties

A volume is defined by its size in the 3 dimensions.

- *Width* Size in X dimension

- *Depth* Size in Y dimension
- *Height* Size in Z dimension

5.1.2 Sampling of the volume




Figure 35: Computation grid type

A computation grid defines the way to sample the volume for computation. In EMF-Visual, 3 types of sampling are available.

- *Regular grid* The volume is sampled along the 3 dimensions with the same sampling step.




Figure 36: Grid volume regular

- *Irregular grid* The sampling along an axis depends on a far distance from EM source along this axis. This far distance is the same for the 3 axis.




Figure 37: Grid volume irregular

- *Irregular grid per axis* The sampling along an axis depends on distance from EM source along this axis. Far distances may be different for the 3 axis.




Figure 38: Grid volume irregular per axis

For each computation volume, each antenna, each band, and each polarisation, EMF-Visual creates one computation result file. Result files are created in folder Results under the same directory than the configuration file.

5.2 Launch computation

To launch a computation, **Simulation > Run**

NB: A volume must have been defined.

The results files are saved in Tecplot format under a directory which name is:

<SceneFileName>_<Year><Month><Day>_<Hour><Minute><Second>-<ComputationMode>.

There are as many files as antenna bands. The name of result file is

"<SceneFileName>_Volume_<VolumeIndex>_AntennaBands_<BandsIndex>.txt".

- <SceneFileName> is the name of the scene file without .scnx extension
- <VolumeIndex> is the index of the computation volume.
- <BandIndex> is the index of the band of for all active antennas.

- <Year><Month><Day>_<Hour><Minute><Second> are the year, month, day, hour, minute and second of the computation.
- <ComputationMode> is "GPU-Advanced" or "CPU-Standard" depending on the version of EMF-VISUAL.

NB: A .dat file is also create which is the binary version for results file.

5.2.1 Results file format

Here the Tecplot file format of result file.

5.2.1.1 Header

```
#Date: <Date>
#Computation on <CPUorGPU> in <StandardOrAdvanced> mode
#Volume matrix
<Matrix>
#Frequency
#<Frequency>
#Antenna Properties
#Antenna Name: <AntennaName>
#Band Name: <BandName>
#Name: <AntennaName>
TITLE = "EMF-FIELD"
VARIABLES = "X", "Y", "Z", "ExModule", "ExPhase", "EyModule", "EyPhase",
"EzModule", "EzPhase"
ZONE T="Data",
I=<PointsCount>, J=1, K=1, F=POINT
```

With

- <Date> Date of computation in format <Year>-<Month>-<Day> <Hour>:<Minute>:<Second>
- <CPUorGPU> CPU if computation was performed in CPU mode, GPU otherwise.
- <StandardOrAdvanced> Standard if computation was performed in standard mode, Advanced otherwise
- <Matrix> For internal use, the 4x4 matrix defining the position and orientation of the volume
- <Frequency> The frequency of the band in Hertz
- <AntennaName> The name of the antenna defined in .src antenna file
- <BandName> The name of the band defined in .src antenna file
- <AntennaID> The ID of the antenna
- <PointsCount> The number of computed points of the volume.

5.2.1.2 Raw data

Results for one computation point are stored line by line. By order a line is composed of

- X coordinate of computed point in meters
- Y coordinate of computed point in meters
- Z coordinate of computed point in meters
- Module of electric field in X axis in V/m
- Module of electric field in Y axis in V/m
- Module of electric field in Z axis in V/m
- Phase of electric field in X axis in radians
- Phase of electric field in Y axis in radians
- Phase of electric field in Z axis in radians

5.3 Results visualisation

EMF-Visual can display one result computation at a time.







Figure 39: Computation Result

To view a computation result

- Check *Show Results*



-  Open new result directory. Select the new directory file from the displayed file browser.
- Select unit among a list
 - Electric Field (V/m)
 - Electric Field (dBV/m)
 - Electric Field (dBmV/m)
 - Electric Field (dB μ V/m)
 - Magnetic Field (A/m)
 - Magnetic Field (dBA/m)
 - Power Density (W/m²)
 - Power Density (mW/cm²)
 - Power Density (μ W/cm²)
 - Field Percentage (public)
 - Field Percentage (worker)
 - Power Percentage (public)
 - Power Percentage (worker)
- *Min legend* and *Max legend* are min and max values used to display results. Clicking on  retrieves min or max value from data.

Results can be visualised with cross section or with iso surfaces once a data file is loaded,

5.3.1 Visualisation

5.3.1.1 Isosurface

To view iso-surface **Check Iso-surface level**. The slider will change value of iso-surface to display.




Figure 40: Iso-surface view

5.3.1.2 Cross section

To display a cross section, a plane has to be added to Tools node. **Right click on Tools node > Add entity > Plane**





Figure 41: Plane in Tools node

Once a plane added to Tools node, it will define a cut plane. Moving and orientating it will update view of cut plane.

Note that several planes can be added.



Property	Value
X (m)	0
Y (m)	0
Z (m)	0
Azimuth (°)	0
Tilt (°)	0
Roll (°)	0
Width/X (m)	10
Depth/Y (m)	10
Height/Z (m)	10
Plane	XY
Clipping mode	Off
<input checked="" type="checkbox"/> Grid	
Grid step size X (m)	1
Grid step size Y (m)	1
Grid step size Z (m)	1

Figure 42: Plane properties

The plane is modelled in the 3D view by a flat box as below with grid for visualisation. The plane is display only when it is selected.




Figure 43: Plane visualisation

The thickness of this box can't be changed. Modifying the height of the box has no effect.

5.3.1.2.1 Plane property

3 pre defined planes can be chosen in EMF-Visual.







Figure 44: Plane orientation property



XY Plane



XY Plane




XY Plane


5.3.1.2.2 Clipping property

If clipping property is not set to *Off*, the defined plane cuts every object in the scene, including iso-surfaces.

- Positive* Iso-surface
- in positive side of plane is cut



- Negative* Iso-surface
- in negative side of plane is cut



5.3.1.2.3 Grid properties




Figure 45: Plane grid property

The sampling of the visualisation grid can be set for each dimension.




Figure 46: 1m sampling






Figure 47: 2m sampling

5.3.2 Recommendation file

Recommendation file is a *.evc file.



 Open new recommendation file *.evc. Select the new file from the displayed file browser. See 6.3 for default recommendation example files.

Once a recommendation file loaded, several areas are displayed depending on the recommendation

- *Public area*

- *Worker area*
- *Forbidden area*




Figure 48: Recommendation example

A recommendation file defines the limits between each area.

Values from recommendation can be modified.




Figure 49: Recommendation properties

5.3.3 Recommendation

Recommendation to apply for exposure computation can be chosen among 4 different recommendations:

- *ICNIRP* - European Union recommendation

- *Safety Code 6-2015* - Canada recommendation
- *FCC* - Us recommendation, FCC Reference Levels June 2013
- *Custom* - Customized recommendation, defined by user in a file. See 5.3.4






Figure 50: List of recommendations

5.3.4 Custom standard file

A custom standard file is an ascii *.txt* file



 Open custom standard file *.txt*. Select the new file from the displayed file browser. This field is not editable if *Custom* recommendation is not selected.

This file provides coefficients for computing reference electric value to display Field or Power Percentage for *public* and *restricted* environments.

NB: Magnetic reference values are deduced from electric reference values with the formula

$$H = E / 120\pi$$

5.3.4.1 Genenic reference value computation formula

For a range of frequencies, the generic formula to compute reference value is:

$$ref = a \cdot f^b$$

with

- *f* frequency in *MHz*
- *a* and *b* coefficients provided by custom standard file.

5.3.4.2 Custom standard file format

A custom standard defines coefficients (*a, b*) for different ranges of frequencies and for *public* and *restricted or worker* environments.

$$\begin{array}{l}
 n \\
 a_0^P \ a_1^P \ \dots \ a_n^P \\
 b_0^P \ b_1^P \ \dots \ b_n^P \\
 f_0^P \ f_1^P \ \dots \ f_{n-1}^P \\
 m \\
 a_0^W \ a_1^W \ \dots \ a_m^W \\
 b_0^W \ b_1^W \ \dots \ b_m^W \\
 f_0^W \ f_1^W \ \dots \ f_{m-1}^W
 \end{array}$$

with

- n the number of frequencies for defining ranges of frequencies for public environment
- a_i^P the coefficient a number i for public environment
- b_i^P the coefficient b number i for public environment
- f_i^P the frequency number i in MHz used to define ranges of frequencies for public environment
- m the number of frequencies for defining ranges of frequencies for worker environment
- a_i^W the coefficient a number i for worker environment
- b_i^W the coefficient b number i for worker environment
- f_i^W the frequency number i in MHz used to define ranges of frequencies for worker environment

Let f be the frequency of an electromagnetic source expressed in MHz .

Let ref^P be the reference value for public environment and ref^W the reference value for worker environment.

$$ref^P = \begin{cases} a_i^P \cdot f^{b_i^P} & \text{if } f_i^P \leq f < f_{i+1}^P \text{ with } i \neq n - 1 \\ a_0^P \cdot f^{b_0^P} & \text{if } f \leq f_0^P \\ a_n^P \cdot f^{b_n^P} & \text{if } f_{n-1}^P < f \end{cases}$$

$$ref^W = \begin{cases} a_i^W \cdot f^{b_i^W} & \text{if } f_i^W \leq f < f_{i+1}^W \text{ with } i \neq m - 1 \\ a_0^W \cdot f^{b_0^W} & \text{if } f \leq f_0^W \\ a_m^W \cdot f^{b_m^W} & \text{if } f_{m-1}^W < f \end{cases}$$

Be careful, there are $n + 1$ coefficients (a_i^P, b_i^P) and n frequencies f_i^P . Frequencies define limits of frequency ranges and the coefficients are defined for each frequency range. The same for worker environment definition, there are $m + 1$ coefficients (a_i^W, b_i^W) and m frequencies f_i^W .

NB: The separators allowed between each values are: space, tabulation, carriage return. The layout of the custom standard file in this document is a suggestion for an easy reading. If the custom standard file is wrong, message "*Custom standard file error*" is displayed and ICNRP recommendation is used by default.

5.3.4.3 Example of custom standard file

Here an example of custom standard file which fits the ICNRP recommendation.

This is a part of ICNRP recommendation:

Frequency range	E-Field Strength (V · m ⁻¹)
1-10 MHz	$87/f^{1/2}$
10-400 MHz	28
400-2000 MHz	$1.375f^{1/2}$
2-300 GHz	61

Figure 51: Reference level for public exposure

Frequency range	E-Field Strength (V · m ⁻¹)
1-10 MHz	$610/f$
10-400 MHz	61
400-2000 MHz	$3f^{1/2}$
2-300 GHz	137

Figure 52: Reference level for occupational exposure

The equivalent custom standard file is

```
87 28 1.375 61
-0.5 0 0.5 0
10 400 2000 3
610 61 3 137
-1 0 0.5 0
10 400 2000
3
```

Below 1MHz, the formula is the same than the frequency range 1-10MHz. Above 300 GHz, formula is the same than the frequency range 2-300GHz.

5.3.5 Legend





Figure 53: Legend

- Legend box displays the legend on screen.
- Color count defines the number of color displayed in legend. By default, the count is 10.

- Coloring method
 - Contouring
 - Mapping



Contouring

Mapping

- Transparency sliders changes transparency of all view results entities such as cross section and iso surface.

5.3.5.1 Coloring method

The mapping method computes a color for each scalar value on the plane. A value greater or equal to the greatest value of the range will have a red color and a value lower or equal to the lowest value a blue color.



Figure 54: Legend in mapping coloring method

The contouring method computes a color for a range of scalar values knowing that the whole range

is divided in several ranges. A value greater than the greatest value of the range will have a red color whereas a value lower than the lowest value a blue color.




Figure 55: Legend in contouring coloring method

5.4 Results Menu




Figure 56: Results menu

With *Results* menu, the user can load the result of a computation, center of computed results and save cross section images.

5.4.1 Save cross section

By clicking on *Save cross section* EMF-Visual will save images of intersection of all planes with all volumes under the results directory See 5.3. Images are saved in *PNG* format.

Name of image is

CrossSection_<PlaneIndex>_volume_<VolumeIndex>_<Year><Month><Day>_<Hour><Minute><Second>.png

with

- <PlaneIndex> is the index of the plane
- <VolumeIndex> is the index of the volume intersected by the plane
- <Year><Month><Day>_<Hour><Minute><Second> are the year, month, day, hour, minute and second of time the *Save cross section* action was launched.

No image is saved under one of these conditions

- No results is loaded
- No plane is activated

The image is saved with legend, ruler to show dimensions of cross section and local frame of the plane.




Figure 57: Example of cross section image

A grid is drawn if grid is displayed. See 5.3.1.2.3.




Figure 58: Cross section image with grid

As the image is projected in the local frame of the cutting plane, if the cutting plane is turned, the image is also rotated.






Figure 59: Cross section image with rotation on cutting plane


6 Delivered features

6.1 3D database

EMF-VISUAL is delivered with a set of 3D objects to create a scene.







6.2 Antennas

Several kind of antennas in *.src format are delivered under *Antennas* directory.

6.2.1 Diagram antenna files

Several diagram files in *.elt format are delivered under *Computer/Database*

6.3 Recommendation files

Recommendation files are delivered under *ConstraintsEnvironments* directory.